

# SCHEDULED MAINTENANCE INTERVALS

## (MAZDA 323, 626, 929, MX3, MX6, RX-7, MIATA, MILLENIA & PROTEGE)

TO BE SERVICED	TYPE OF SERVICE	VEHICLE MILEAGE INTERVAL (x1000)												
		7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5
Engine oil & filter④	R	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Air cleaner element	R				✓				✓				✓	
Engine coolant③	R				✓				✓				✓	
Spark plugs (except Millenia KJ engine)	R				✓				✓				✓	
Spark plugs (Millenia KJ engine)	R								✓					
Automatic transaxle fluid	S/I				✓				✓				✓	
Bolts & nuts on chassis & body	S/I				✓				✓				✓	
Brake lines, hoses & connections	S/I				✓				✓				✓	
Cooling system	S/I				✓				✓				✓	
Disc brakes	S/I				✓				✓				✓	
Drive belts (Millenia①)	S/I				✓				✓				✓	
Drive shaft dust boots	S/I				✓				✓				✓	
Exhaust system heat shield	S/I				✓				✓				✓	
Front & rear suspension ball joints	S/I				✓				✓				✓	
Fuel lines & hoses	S/I				✓				✓				✓	
Idle speed⑤	S/I				✓				✓				✓	
Steering operation & linkages	S/I				✓				✓				✓	
Engine timing belt②	R								✓					
Fuel filter	R								✓					
Manual transmission oil (Miata)	R								✓					
Hose & tube for emission	S/I								✓					

① (Millenia KJ engine) - replace every 105,000 miles.

② (Calif.) - inspect every 30,000 miles & replace at 105,000 miles (if not replaced previously).

③ (Millenia) - replace initially at 45,000 miles, & every 30,000 miles thereafter.

④ (RX-7) - change every 5000 miles.

⑤ (RX-7 & 929) - check every 15,000 miles.

R - Replace      S/I - Service or Inspect

# **SCHEDULED MAINTENANCE INTERVALS**

**(MAZDA 323, 626, 929, MX3, MX6, RX-7, MIATA, MILLENIA & PROTEGE) (Cont.)**

---

## **FREQUENT OPERATION MAINTENANCE (SEVERE SERVICE)**

**If a vehicle is operated under any of the following conditions it is considered severe service:**

- **Extremely dusty areas.**
- **50% or more of the vehicle operation is in 32°C (90°F) or higher temperatures, or constant operation in temperatures below 0°C (32°F).**
- **Prolonged idling (vehicle operation in stop and go traffic).**
- **Frequent short running periods (engine does not warm to normal operating temperatures).**
- **Police, taxi, delivery usage or trailer towing usage.**

**Oil & oil filter change – change every 5000 miles.**

**Oil & oil filter change (Puerto Rico) - change every 3000 miles.**

**Air cleaner element – service or inspect every 15,000 miles.**

**Automatic transaxle fluid - service or inspect every 15,000 miles.**

**Bolts & nuts on chassis & body - tighten every 15,000 miles.**

**Disc brakes - service or inspect every 15,000 miles.**